

# Power Foam<sup>®</sup> Carburetor and Induction-System Cleaner for Two- and Four-Stroke Gasoline Engines

AMSOIL Power Foam<sup>®</sup> (APF) improves engine performance by removing gum, varnish and carbon deposits that affect power, operation, idle and fuel economy. Power Foam cleans intake valves, intake manifolds and throttle plates to keep the combustion intake system running at peak efficiency. Effective in both two- and four-stroke gasoline engines, Power Foam helps reduce engine ping and keeps carburetors and injector systems operating like new. Power Foam is safe for fuel injectors, catalytic converters and emissions-control devices. It will not damage seals, gaskets, rubber or plastic materials commonly used in gasoline engines.

## **Performance Features**

- Cleans deposits from ethanol and degraded fuel.
- **Removes** gum and varnish.
- Maximizes horsepower.
- Restores startability.
- Helps improve fuel economy.
- Reduces pollution.

## **Applications**

- UTVs/ATVs Marine Engines Motorcycles
- Lawncare Equipment 
  Tractors
  Cars & Trucks

#### **Directions**

- 1. Protect painted surfaces and mass airflow sensors (MAF) from spray.
- 2. Ensure application is in a well-ventilated area.
- 3. Run engine to normal operating temperature and remove air cleaner assembly.
- 4. While engine is running, spray Power Foam directly into throttle body as fast as possible without stalling engine. It is common to have to rev the engine above idle to facilitate this process. It is also common to see white smoke coming out of your exhaust.
- Once the sound of the engine improves, spray enough Power Foam to choke out the engine. Shut off engine and allow to sit for 10-15 minutes.
- 6. Replace air cleaner.
- 7. Restart engine. Repeat application of Power Foam as needed.
- 8. In four-stroke engines, an oil change is recommended after treatment.

In extreme cases, disassemble carburetor and soak parts.

Do not apply while equipment is in motion. Do not apply to hot surfaces. Test on small area before using on rubber, painted or plastic surfaces. Wipe off overspray. <image><section-header>

### Recommendations

Avoid contact with hoses and exterior plastic components. To prevent the dissolving of paint, do not overspray. Clean any overspray immediately to prevent unintentional component damage. Power Foam is not recommended for use in diesel engines, GDI engines or as a general-purpose degreaser.

#### Disposal

Aerosols may have different disposal requirements than other wastes in your area. Dispose of contents and container in accordance with all federal, state/provincial and local regulations.

#### **TECHNICAL SERVICES**

For immediate answers to your technical questions call (715) 399-8324 (TECH) between 8 a.m. and 5 p.m. Central time or email tech@AMSOIL.com.

#### PRODUCT AVAILABILITY

Power Foam is available in 18-ounce spray cans. Not available in Canada or California.

#### **PRODUCT WARRANTY**

AMSOIL products are backed by a Limited Liability Warranty. For complete information visit AMSOIL.com/warranty.aspx.

#### **HEALTH & SAFETY**

This product is not expected to cause health concerns when used for the intended applications and according to the recommendations in the Safety Data Sheet (SDS). An SDS is available online at AMSOIL.com or upon request at (715) 392-7101. **Keep Out of Reach of Children**.

ZMSTIL.

*The First in Synthetics* • Jeff Fisher

866-292-4700

www.SyntheticOils.us

AMSOIL INC., 1 AMSOIL Center, Superior, WI 54880 • 715-392-7101 • Printed in the USA. © 2024, AMSOIL INC. All rights reserved. The AMSOIL logo is a registered trademark of AMSOIL INC. AMSOIL products and Dealership information are available from your local full-service AMSOIL Dealer.



Produced under the authority of AMSOIL INC.; Formulated, blended and packaged in the USA.; AMSOIL INC., Superior, WI 54880 USA.

## DATA SHEET